APPENDIX D EVENT ACTION PLANS

Appendix D:

Table D-1: Event / Action Plan for Air Quality

	ACTION			
EVENT	ET	IEC	PERMIT HOLDER	CONTRACTOR
ACTION LEVE	L			
1. Exceedance for one sample	1. Identify source, investigate the causes of exceedance and propose remedial measures; 2. Inform IEC, ER and Contractor; 3. Repeat measurement to confirm finding; and 4. Increase monitoring frequency to daily.	1. Check monitoring data submitted by ET; 2. Check Contractor's working method.	1. Notify Contractor.	Rectify any unacceptable practice: Amend working methods if appropriate.
2. Exceedance for two or more consecutive samples	1. Identify source; 2. Inform IEC, ER and Contractor; 3. Advise the WKCDA on the effectiveness of the proposed remedial measure; 4. Repeat measurements to confirm findings; 5. Increase monitoring frequency to daily; 6. Discuss with IEC and Contractor on remedial actions required; 7. If exceedance continues, arrange meeting with IEC and ER; and	 Check monitoring data submitted by ET; Check Contractor's working method; Discuss with ET and Contractor on possible remedial measures; Advise the ET on the effectiveness of the proposed remedial measures; and Monitor Implementation of remedial measures. 	1. Confirm receipt of notification of failure in writing; 2. Notify Contractor; and 3. Ensure remedial measures properly implemented.	1. Submit proposals for remedial to ER within 3 working days of notification; 2. Implement the agreed proposals; and 3. Amend proposal if appropriate.

	ACTION				
EVENT	ET	IEC	PERMIT HOLDER	CONTRACTOR	
	8. If exceedance stops, cease additional monitoring.				
LIMIT LEVEL					
1.Exceedance for one sample	 Identify source, investigate the causes of exceedance and propose remedial measures; Inform ER, Contractor and EPD; Repeat measurement to confirm finding; Increase monitoring frequency to daily; and Assess effectiveness of Contractor's remedial actions and keep IEC, EPD and the ER informed of the results. 	 Check monitoring data submitted by ET; Check Contractor's working method; Discuss with ET and Contractor on possible remedial measures; Advise the ER on the effectiveness of the proposed remedial measures; and Monitor the implementation of remedial measures. 	1. Confirm receipt of notification of failure in writing; 2. Notify Contractor; and 3. Ensure remedial measures properly implemented.	 Take immediate action to avoid further exceedance; Submit proposals for remedial actions to IEC within 3 working days of notification; Implement the agreed proposals; and Amend proposal if appropriate. 	
2.Exceedance for two or more consecutive samples	 Notify IEC, the ER, Contractor and EPD; Identify source; Repeat measurement to confirm findings; Increase monitoring frequency to daily; Carry out analysis of Contractor's working procedures to determine 	 Check monitoring data submitted by ET; Check Contractor's working method; Discuss amongst ER, ET, and Contractor on the potential remedial actions; 	1. Confirm receipt of notification of failure in writing; 2. Notify Contractor; 3. In consultation with IEC, agree with the Contractor on the remedial measures to be implemented;	 Take immediate action to avoid further exceedance; Submit proposals for remedial actions to IEC within 3 working days of notification; Implement the agreed proposals; 	

ELYCNYO.	ACTION				
EVENT	ET	IEC	PERMIT HOLDER	CONTRACTOR	
	possible mitigation to be implemented; 6. Arrange meeting with IEC, and ER to discuss the remedial actions to be taken; 7. Assess effectiveness of Contractor's remedial actions and keep IEC, EPD and ER informed of the results; and 8. If exceedance stops, cease additional monitoring.	4. Review Contractor's remedial actions whenever necessary to assure their effectiveness and advise the ER accordingly; and 5. Monitor implementation of remedial measures.	4. Ensure remedial measures properly implemented; and 5. If exceedance continues, consider what portion of the work is responsible and instruct the Contractor to stop that portion of work until the exceedances are abated.	 4. Resubmit proposals if problem still not under control; and 5. Stop the relevant portion of works as determined by the ER until the exceedance is abated. 	

 $Abbreviations: ET-Environmental\ Team,\ IEC-Independent\ Environmental\ Checker$

Table D-2: Event / Action Plan for Construction Noise

EVENT	ACTION			
	ET	IEC	PERMIT HOLDER	CONTRACTOR
Action Level	 Notify ER, IEC and Contractor; Carry out investigation; Report the results of investigation to the IEC, ER and Contractor; Discuss with the IEC and Contractor on remedial measures required; and Increase monitoring frequency to check mitigation effectiveness. 	 Review the monitoring data submitted by the ET; Review the proposed remedial measures by the Contractor and advise ER; and Advise the ER on the effectiveness of the proposed remedial measures. 	 Confirm receipt of notification of failure in writing; Notify Contractor; In consolidation with the IEC, agree with the Contractor on the remedial measure to be implemented: and Supervise the implementation of remedial measure. 	1. Submit noise mitigation proposals to IEC and ER; and 2. Implement noise mitigation proposals.
Limit Level	1. Inform IEC, ER and Contractor and EPD; 2. Repeat measurements to confirm findings; 3. Increase the monitoring frequency; 4. Identify source and investigate the cause of exceedance; 5. Carry out analysis of Contractor's working procedures; 6. Discuss with the IEC, Contractor and ER on	1. Discuss amongst the ER, ET, and Contractor on the potential remedial actions; and 2. Review Contractor's remedial actions whenever necessary to assure their effectiveness and advise the ER accordingly;	1. Confirm receipt of notification of failure in writing; 2. Notify the Contractor; 3. In consolidation with the IEC, agree with the Contractor on the remedial measures to be implemented; 4. Supervise the implementation of remedial measures; and 5. If exceedance continues, consider	1. Take immediate action to avoid further exceedance; 2. Submit proposals for remedial actions to the IEC and ER within 3 working days of notification; 3. Implement the agreed proposals; 4. Submit further proposal if problem still not under control; and 5. Stop the relevant portion of works as

EVENT	ACTION			
	ET	IEC	PERMIT HOLDER	CONTRACTOR
	remedial measure		stopping the	determined by the ER
	required;		Contractor to	until the exceedance
	7. Assess effectiveness		continue working in	is abated.
	of Contractor's		that portion of work	
	remedial actions and		which causes the	
	keep IEC, EPD and		exceedance until	
	ER informed of the		the exceedance is	
	results; and		abated.	
	8. If exceedance stops,			
	cease additional			
	monitoring.			

 $Abbreviations: ET-Environmental\ Team,\ IEC-Independent\ Environmental\ Checker$

Table D-3: Event / Action Plan for Landscape and Visual Mitigation Measures

EVENT		ACT	TION		
	ET	IEC	PERMIT HOLDER	CONTRACTOR	
Non-	Identify source. Inform	Check report.	Notify Contractor.	Amend working	
conformity on	IEC and ER.	Check Contractor's	Ensure remedial	methods to prevent	
one occasion	Discuss remedial actions	working method.	measures are properly	recurrence of	
	with IEC, ER and	Discuss with ET and	implemented	nonconformity.	
	Contractor.	Contractor on possible		Rectify damage and	
	Monitor remedial	remedial measures.		undertake additional	
	actions until rectification	Advise ER on		action necessary.	
	has been completed.	effectiveness of			
		proposed remedial			
		measures.			
		Check implementation			
		of remedial measures.			
Repeated	Identify source.	Check monitoring	Notify Contractor.	Amend working	
Nonconformity	Inform IEC and ER.	report. Check	Ensure remedial	methods to prevent	
	Increase monitoring	Contractor's working	measures are properly	recurrence of	
	frequency. Discuss	method.	implemented.	nonconformity.	
	remedial actions with	Discuss with ET and		Rectify damage and	
	IEC, ER and Contractor.	Contractor on possible		undertake additional	
	Monitor remedial	remedial measures.		action necessary.	
	actions until rectification	Advise ER on			
	has been completed.	effectiveness of			
	If non-conformity stops,	proposed remedial			
	cease additional	measures.			
	monitoring.	Supervise			
		implementation of			
		remedial measures.			

 $Abbreviations: ET-Environmental\ Team,\ IEC-Independent\ Environmental\ Checker$