APPENDIX D EVENT ACTION PLANS

Appendix I:

Table D-1: Event / Action Plan for Air Quality

	ACTION			
EVENT	ET	IEC	PERMIT HOLDER	CONTRACTOR
ACTION LEVE	L			
1. Exceedance for one sample	1. Identify source, investigatethe causes of exceedance and propose remedial measures; 2. Inform IEC,ER and Contractor; 3. Repeat measurement to confirm finding; and 4. Increase monitoring frequency to daily.	1. Check monitoring data submitted by ET; 2. Check Contractor's working method.	1. Notify Contractor.	1. Rectify any unacceptable practice: 2. Amend working methods if appropriate.
2. Exceedance for two or more consecutive samples	 Identify source; Inform IEC, ER andContractor; Advise the WKCDA on theeffectiveness of the proposed remedial measure; Repeat measurements to confirm findings; Increase monitoring frequency to daily; Discuss with IEC and Contractor on remedialactions required; If exceedance continues, arrange meeting with IECand ER; and 	 Check monitoring data submitted by ET; Check Contractor's working method; Discuss with ET and Contractor on possible remedial measures; Advise the ET on the effectiveness of the proposed remedial measures; and Monitor Implementation of remedial measures. 	1. Confirm receipt of notification of failure in writing; 2. Notify Contractor; and 3. Ensure remedial measures properly implemented.	 Submit proposals for remedial to ER within 3 working days of notification; Implement the agreed proposals; and Amend proposal if appropriate.

	ACTION			
EVENT	ET	IEC	PERMIT HOLDER	CONTRACTOR
	8. If exceedance stops, cease additional monitoring.			
LIMIT LEVEL				
1.Exceedance for one sample	 Identify source, investigate the causes of exceedance and propose remedial measures; Inform ER, Contractor and EPD; Repeat measurement to confirm finding; Increase monitoring frequency to daily; and Assess effectiveness of Contractor's remedial actions and keep IEC, EPD and the ER informed of the results. 	 Check monitoring data submitted byET; Check Contractor's working method; Discuss with ET and Contractor on possible remedial measures; Advise the ER on the effectiveness ofthe proposed remedial measures; and Monitor the implementation of remedial measures. 	1. Confirm receipt ofnotification of failure in writing; 2. Notify Contractor;and 3. Ensure remedial measures properly implemented.	1. Take immediate actionto avoid further exceedance; 2. Submit proposals for remedial actions to IECwithin 3 working days of notification; 3. Implement the agreedproposals; and 4. Amend proposal if appropriate.
2.Exceedance for two or more consecutive samples	 Notify IEC, the ER, Contractor and EPD; Identify source; Repeat measurement to confirm findings; Increase monitoring frequency to daily; Carry out analysis of Contractor's working procedures to determine 	1. Check monitoring data submitted byET; 2. Check Contractor's working method; 3. Discuss amongst ER, ET, and Contractor on the potential remedial actions;	1. Confirm receipt ofnotification of failure in writing; 2. Notify Contractor; 3. In consultation with IEC, agree with the Contractor on theremedial measures to be implemented;	1. Take immediate action avoid further exceedance; 2. Submit proposals for remedial actions to IEC within 3 working days of notification; 3. Implement the agreedproposals;

EXTENSE	ACTION			
EVENT	ET	IEC	PERMIT HOLDER	CONTRACTOR
	possible mitigation to	4. Review Contractor's	4. Ensure remedial	4. Resubmit proposals
	be implemented;	remedial actions	measures	if problem still not
	6. Arrange meeting with	whenever necessary to	properly	undercontrol; and
	IEC, and ER to discuss	assuretheir	implemented;	5. Stop the relevant
	the remedial actions to	effectiveness and	and	portion of works as
	be taken;	advise the ER	5. If exceedance	determined by the
	7. Assess effectiveness of	accordingly; and	continues,	ER until the
	Contractor's remedial	5. Monitor	consider what	exceedance is
	actions and keep IEC,	implementation of	portion of the	abated.
	EPD and ER informed	remedial measures.	work is	
	of the results; and		responsible and	
	8. If exceedance stops,		instruct the	
	cease additional		Contractor to	
	monitoring.		stopthat portion	
			of work until	
			the exceedances is	
			abated.	

 $Abbreviations: ET-Environmental\ Team,\ IEC-Independent\ Environmental\ Checker$

Table D-2: Event / Action Plan for Construction Noise

EVENT	ACTION			
	ET	IEC	PERMIT HOLDER	CONTRACTOR
Action Level	 Notify ER, IEC and Contractor; Carry out investigation; Report the results of investigation to the IEC, ER and Contractor; Discuss with the IEC and Contractor on remedial measures required; and Increase monitoring frequency to check mitigation effectiveness. 	1. Review the monitoring data submitted by the ET; 2. Review the proposed remedial measures by the Contractor and advise ER; and 3. Advise the ER on the effectiveness of the proposed remedial measures.	1. Confirm receipt of notification of failure in writing; 2. Notify Contractor; 3. In consolidation with the IEC, agree with the Contractor on the remedial measure to be implemented: and 4. Supervise the implementation of remedial measure.	1. Submit noise mitigation proposals to IEC and ER; and 2. Implement noise mitigation proposals.
Limit Level	1. Inform IEC, ER and Contractor and EPD; 2. Repeat measurements to confirm findings; 3. Increase the monitoring frequency; 4. Identify source and investigate the cause of exceedance; 5. Carry out analysis of Contractor's working procedures; 6. Discuss with the IEC, Contractor and ER on	1. Discuss amongst the ER, ET, and Contractor on the potential remedial actions; and 2. Review Contractor's remedial actions whenever necessary to assure their effectiveness and advise the ER accordingly;	1. Confirm receipt of notification of failure in writing; 2. Notify the Contractor; 3. In consolidation with the IEC, agree with the Contractor on the remedial measures to be implemented; 4. Supervise the implementation of remedial measures; and 5. If exceedance continues, consider	1. Take immediate action to avoid further exceedance; 2. Submit proposals for remedial actions to the IEC and ER within 3 working days of notification; 3. Implement the agreed proposals; 4. Submit further proposal if problem still not under control; and 5. Stop the relevant portion of works as

EVENT	ACTION			
	ET	IEC	PERMIT HOLDER	CONTRACTOR
	remedial measure		stopping the	determined by the ER
	required;		Contractor to	until the exceedance
	7. Assess effectiveness		continue working in	is abated.
	of Contractor's		that portion of work	
	remedial actions and		which causes the	
	keep IEC, EPD and		exceedance until	
	ER informed of the		the exceedance is	
	results; and		abated.	
	8. If exceedance stops,			
	cease additional			
	monitoring.			

 $Abbreviations: ET-Environmental\ Team,\ IEC-Independent\ Environmental\ Checker$

Table D-3: Event / Action Plan for Landscape and Visual Mitigation Measures

EVENT	ACTION			
	ET	IEC	PERMIT HOLDER	CONTRACTOR
Non-conformity on one occasion	Identify source. Inform IEC and ER. Discuss remedial actions with IEC, ER and Contractor. Monitor remedial actions until rectification has been completed.	Check report. Check Contractor's working method. Discuss with ET and Contractor on possible remedial measures. Advise ER on effectiveness of proposed remedial measures. Check implementation of remedial measures.	Notify Contractor. Ensure remedial measures are properly implemented	Amend working methods to prevent recurrence of nonconformity. Rectify damage and undertake additional action necessary.
Repeated Nonconformity	Identify source. Inform IEC and ER. Increase monitoring frequency. Discuss remedial actions with IEC, ER and Contractor. Monitor remedial actions until rectification has been completed. If non-conformity stops, cease additional monitoring.	Check monitoring report. Check Contractor's working method. Discuss with ET and Contractor on possible remedial measures. Advise ER on effectiveness of proposed remedial measures. Supervise implementation of remedial measures.	Notify Contractor. Ensure remedial measures are properly implemented.	Amend working methods to prevent recurrence of nonconformity. Rectify damage and undertake additional action necessary.

 $Abbreviations: ET-Environmental\ Team,\ IEC-Independent\ Environmental\ Checker$